



retro

*tradition in
a modern design*



The range of RETRO switches and outlets is introducing an original design inspired by combination of rotary ceramic switches from the time of 1930 ´s and world-unique functionalist architecture of Zlin city, where OBZOR comes from. Therefore RETRO line finds its place not only in rustic, vintage, but also in modern loft, minimalist and industrial interiors.



A few clever interior complements, such as switches and outlets, will add to your interior's charm. Our RETRO switch is not just an unobtrusive device that fulfils its essential purpose but is equivalent design companion to the rest of household equipment.

Let us introduce you switches that are everything but discreet. No lines, edges or restraint in dimensions. RETRO switches are round, relatively massive and controlled by a rotary handle.

RETRO switches excel in modern lofts and other minimalist interiors. They will fit well on revealed brick walls, concrete walls as well as on ceramic tiles. RETRO will embellish also rustic interior, e.g. in rural chalets.

RETRO line offers usual range of fittings according to present-day requirements for comfortable living:

- various switching fittings
- shutter controller
- classic outlet (schuko version available)
- computer outlet
- TV outlet
- SAT outlet
- HDMI outlet
- USB charging outlet
- thermostats and motion sensors

There are four collections of noble natural materials to choose from:

- glass
- ceramics
- solid wood

glass collection

Design that is not ostentatious or complicated, but simply great. Design that brings up the beauty of the material, real glass. Timeless switches from this collection will highlight modern furnished interiors as well as masterpieces of modern architecture.



glass white frame
/ OBZ handle patina



glass black frame
/ BTA handle silver



glass white frame
/ outlet cover black matt



DO YOU WANT TO
KNOW MORE?
www.retrovypinac.cz/en





ceramic collection

Here we combine white and black ceramic frames and covers. In case of switches you can choose from three different types of control handles that will bring up fresh and exciting combinations!



ceramic white frame / cover white
/ OBZ handle patina



ceramic black frame / cover white
/ single toggle black



ceramic black frame / cover black
/ BTA handle white

hand painted collection

Hand painted white ceramic collection offers single frames in four folklore patterns. These can be combined with any of our covers and handles / toggles.



pattern 1 / cover white
/ double toggle white



pattern 2 / cover white
/ ZLN handle patina



pattern 3 / cover white
/ OBZ handle patina



wood collection

In this collection we present solid wood frames where you can choose between light oak, dark stained oak and maple in combination with white or cover black.



wooden maple frame / cover white / BTA handle patina



wooden light oak frame / cover black / single toggle white



wooden dark stained oak frame / cover white / double toggle black

frames


glass



wood **



ceramic ***







- * Until stocks are sold out
- ** For wooden frames we use only solid wood therefore each frame is unique and tone/pattern might slightly vary.
- *** The painted RETRO frames are available by order only.



ORDER CODE:
DSR 00-00000-11XX

frame multiplicities

	DSR 00-00000-11XX	dimensions (h*w) 97*97 mm all collections
	DSR 00-00000-12XX	dimensions (h*w) 97*168 mm ceramic (not painted), wood, glass
	DSR 00-00000-13XX	dimensions (h*w) 97*239 mm ceramic (not painted), wood
	DSR 00-00000-14XX	dimensions (h*w) 97*310 mm wood



Fittings and outlets can be combined within up to fourfold frame wall mounted in horizontal or vertical position. Same frame can be used for both options.

sets



switch arrangement
1, 2, 5, 6, 7, 1/0,
shutter switch



switch (glass) arrangement
1, 2, 5, 6, 7, 1/0,
shutter switch



single toggle switch
arrangement 1, 2, 6, 7, 1/0
press button up to 24 V



double toggle switch
arrangement 5, 6+6, 1/0 + 1/0
shutter switch
press button up to 24 V



LED dimmer



USB-A outlet
/ USB-A charging outlet



HDMI outlet



USB-C charging outlet



PC outlet
Cat. 5E / Cat. 6



TV outlet



SAT outlet



single outlet



schuko
single outlet



thermostat
(available only in wooden
and glass frames)



motion sensor
(available only in wooden
and glass frames)

covers



switch cover white
+ white BTA handle
DSR 00-01201-0000



switch cover black
+ white BTA handle
DSR 00-02201-0000



HDMI, USB, TV, SAT
outlet cover, white
DSR 00-91000-0000



switch cover white
+ black BTA handle
DSR 00-01202-0000



switch cover black
+ black BTA handle
DSR 00-02202-0000



HDMI, USB, TV, SAT
outlet cover, black
DSR 00-92000-0000



switch cover white
+ patina BTA handle
DSR 00-01203-0000



switch cover black
+ patina BTA handle
DSR 00-02203-0000



PC outlet cover,
white
DSR 00-93000-0000



switch cover white
+ patina OBZ handle
DSR 00-01103-0000



switch cover black
+ patina OBZ handle
DSR 00-02103-0000



PC outlet cover,
black
DSR 00-94000-0000



switch cover white
+ patina ZLN handle
DSR 00-01303-0000



switch cover black
+ patina ZLN handle
DSR 00-02303-0000



outlet cover,
white
DSR 00-Z1000-0000



cover for a LED dimmer
rotary button
DSR 00-03401-0000



cover for a LED dimmer
rotary button
DSR 00-03434-0000



outlet cover,
black matt
DSR 00-Z2000-0000



cover for a LED dimmer
rotary button
DSR 00-04401-0000



cover for a LED dimmer rotary
button black/black mat
DSR 00-04434-0000



schuko outlet cover,
white
DSR 00-S3000-0000



blind cover
white
DSR 60-61000-0000



blind cover
black
DSR 60-62000-0000



schuko outlet cover,
black matt
DSR 00-S4000-0000



For RETRO series switches, a long-proven cam switch mechanism is used.



Toggle switches use a rocker mechanism.



Switch covers and communication outlets cannot be used for RETRO glass collection. You can find covers for RETRO glass on page 21.




Switch covers come with screws supplied in pair in both silver and gold so you can choose which one fits better in your project.


fittings / outlets



fitting, arrangement 1
singlepole switch
16 AX, 250 V AC
DSR 01-00000-0000



HDMI outlet
1 connector: HDMI female
DSR 92-00000-0000



2P+PE outlet
single, cover white safety shutters
16 A, 250 V AC
DSR Z1-Z1000-0000



fitting, arrangement 2
twopole switch
16 AX, 250 V AC
DSR 02-00000-0000




USB-A outlet
1 connector: USB 3.0 female
DSR 94-00000-0000



2P+PE outlet
single, black matt cover safety shutters
16 A, 250 V AC
DSR Z1-Z2000-0000



fitting, arrangement 5
serial change-over switch
16 AX, 250 V AC
DSR 05-00000-0000



USB-A charging outlet
1 connector: USB 3.0 female + charger (2100 mA)
DSR 95-00000-0000



2P+PE schuko outlet
single, cover white safety shutters
16 A, 250 V AC
DSR S2-S3000-0000



fitting, arrangement 6
AC change-over switch
16 AX, 250 V AC
DSR 06-00000-0000



TV outlet
1 connector: IEC female
DSR 97-00000-0000



2P+PE schuko outlet
single, black matt cover safety shutters
16 A, 250 V AC
DSR S2-S4000-0000



fitting, arrangement 7
crossbar switch
16 AX, 250 V AC
DSR 07-00000-0000



SAT outlet
1 connector: female
DSR 99-00000-0000



blind cover
DSR 60-61000-0000



fitting, arrangement 1/0
switching controller
16 AX, 250 V AC
DSR 10-00000-0000



PC Cat. 5E outlet
1 connector: RJ45 Cat. 5E UTP
DSR 93-00000-0000




blind cover
DSR 60-62000-0000



fitting for shutter controller
rotary
16 AX, 230 V AC
DSR 22-00000-0000



PC Cat. 6 outlet
1 connector: RJ45 Cat. 6 UTP
DSR 98-00000-0000



LED dimmer with arrangement 6
230 V AC, load 0-100 W LED, 10-250 W incandescent light bulb
DSR 23-00000-0000



3 gang 1 way switch
16 AX, 230V AC
DSR 03-00000-0000



USB-C charging outlet
1 connector: USB-C charger 2,1 A, 10,5 W
DSR 9C-00000-0000

fittings with covers & toggles



fitting, arrangement 1
single pole switch
10 AX, 250 V AC
DPR 01-01001-0000 cover white / single toggle white
DPR 01-01002-0000 cover white / single toggle black
DPR 01-01003-0000 cover white / single toggle patina
DPR 01-02001-0000 cover black / single toggle white
DPR 01-02002-0000 cover black / single toggle black
DPR 01-02003-0000 cover black / single toggle patina




press button 1/0, up to 24 V
50mA, 24 V DC
DPR 17-01001-0000 cover white / single toggle white
DPR 17-01002-0000 cover white / single toggle black
DPR 17-01003-0000 cover white / single toggle patina
DPR 17-02001-0000 cover black / single toggle white
DPR 17-02002-0000 cover black / single toggle black
DPR 17-02003-0000 cover black / single toggle patina



fitting, arrangement 2
two pole switch
10 AX, 250 V AC
DPR 02-01001-0000 cover white / single toggle white
DPR 02-01002-0000 cover white / single toggle black
DPR 02-01003-0000 cover white / single toggle patina
DPR 02-02001-0000 cover black / single toggle white
DPR 02-02002-0000 cover black / single toggle black
DPR 02-02003-0000 cover black / single toggle patina



fitting, arrangement 1/0 + 1/0
switching controller, double
10AX, 250 V AC
DPR 11-03001-0000 cover white / double toggle white
DPR 11-03002-0000 cover white / double toggle black
DPR 11-03003-0000 cover white / double toggle patina
DPR 11-04001-0000 cover black / double toggle white
DPR 11-04002-0000 cover black / double toggle black
DPR 11-04003-0000 cover black / double toggle patina



fitting, arrangement 5
serial change-over switch
10 AX, 250 V AC
DPR 05-03001-0000 cover white / double toggle white
DPR 05-03002-0000 cover white / double toggle black
DPR 05-03003-0000 cover white / double toggle patina
DPR 05-04001-0000 cover black / double toggle white
DPR 05-04002-0000 cover black / double toggle black
DPR 05-04003-0000 cover black / double toggle patina



fitting for shutter controller
10 AX, 250 V AC
DPR 16-03001-0000 cover white / double toggle white
DPR 16-03002-0000 cover white / double toggle black
DPR 16-03003-0000 cover white / double toggle patina
DPR 16-04001-0000 cover black / double toggle white
DPR 16-04002-0000 cover black / double toggle black
DPR 16-04003-0000 cover black / double toggle patina



fitting, arrangement 6
AC change-over switch
10 AX, 250 V AC
DPR 06-01001-0000 cover white / single toggle white
DPR 06-01002-0000 cover white / single toggle black
DPR 06-01003-0000 cover white / single toggle patina
DPR 06-02001-0000 cover black / single toggle white
DPR 06-02002-0000 cover black / single toggle black
DPR 06-02003-0000 cover black / single toggle patina




double press button 1/0+1/0, up to 24 V
50mA, 24 V DC
DPR 18-03001-0000 cover white / double toggle white
DPR 18-03002-0000 cover white / double toggle black
DPR 18-03003-0000 cover white / double toggle patina
DPR 18-04001-0000 cover black / double toggle white
DPR 18-04002-0000 cover black / double toggle black
DPR 18-04003-0000 cover black / double toggle patina



fitting, arrangement 7
crossbar switch
10 AX, 250 V AC
DPR 07-01001-0000 cover white / single toggle white
DPR 07-01002-0000 cover white / single toggle black
DPR 07-01003-0000 cover white / single toggle patina
DPR 07-02001-0000 cover black / single toggle white
DPR 07-02002-0000 cover black / single toggle black
DPR 07-02003-0000 cover black / single toggle patina




fitting, arrangement 6+6
double AC change-over switch
10 AX, 250 V AC
DPR 66-03001-0000 cover white / double toggle white
DPR 66-03002-0000 cover white / double toggle black
DPR 66-03003-0000 cover white / double toggle patina
DPR 66-04001-0000 cover black / double toggle white
DPR 66-04002-0000 cover black / double toggle black
DPR 66-04003-0000 cover black / double toggle patina



fitting, arrangement 1/0
switching controller
10 AX, 250 V AC
DPR 10-01001-0000 cover white / single toggle white
DPR 10-01002-0000 cover white / single toggle black
DPR 10-01003-0000 cover white / single toggle patina
DPR 10-02001-0000 cover black / single toggle white
DPR 10-02002-0000 cover black / single toggle black
DPR 10-02003-0000 cover black / single toggle patina

toggle colors / metal



i **IMPORTANT:** Recommended min. depth of installation box for RETRO series is 60 mm. For more information, see the chapter Technical drawings or contact our sales department. Connectors for keystone outlets can also be supplied in black color.

i RETRO toggle switches are suitable for installation into standard installation boxes. For more information, see the chapter Technical drawings or contact our sales department. Toggle is always an integral part of the fitting and the cover is supplied with the device. Not for sale separately.

thermostats and motion sensors



EBERLE analogue ROOM thermostat under plaster mounting

- DSR 2T-00000-1130 white glass
- DSR 2T-00000-1131 black glass
- DSR 2T-00000-1121 light oak
- DSR 2T-00000-1122 dark stained oak
- DSR 2T-00000-1123 maple



EBERLE analogue FLOOR thermostat under plaster mounting, with sensor

- DSR 3T-00000-1130 white glass
- DSR 3T-00000-1131 black glass
- DSR 3T-00000-1121 light oak
- DSR 3T-00000-1122 dark stained oak
- DSR 3T-00000-1123 maple



digital thermostat EBERLE universal

- DSR 4T-00000-1130 white glass
- DSR 4T-00000-1131 black glass
- DSR 4T-00000-1121 light oak
- DSR 4T-00000-1122 dark stained oak
- DSR 4T-00000-1123 maple



move sensor B.E.G

- DSR BX-00000-1130 white glass
- DSR BX-00000-1131 black glass
- DSR BX-00000-1121 light oak
- DSR BX-00000-1122 dark stained oak
- DSR BX-00000-1123 maple

i For floor connection with our digital thermostat you need to add extra DSR 56 floor sensor.

i For more thermostat info go to page 72. Thermostats are available assembled with frames only.

i For more motion sensor info go to page 73, X = chosen motion sensor type. Available assembled with frame only.



glass collection



BTA handle white + frame

- DSR XX-00201-1130 white
- DSR XX-00201-1131 black *



BTA handle black + frame

- DSR XX-00202-1130 white
- DSR XX-00202-1131 black *



OBZ handle patina + frame

- DSR XX-00103-1130 white



single outlet

- DSR Z1-Z1000-Z130 white, white cover
- DSR Z1-Z1000-Z131 black *, white cover
- DSR Z1-Z2000-Z130 white, black cover
- DSR Z1-Z2000-Z131 black *, black cover



schuko single outlet

- DSR S2-S3000-Z130 white, white cover
- DSR S2-S3000-Z131 black *, white cover
- DSR S2-S4000-Z130 white, black cover
- DSR S2-S4000-Z131 black *, black cover



HDMI outlet

- DSR 92-00000-U130 white
- DSR 92-00000-U131 black *



PC outlet

- DSR 93-00000-P130 Cat. 5E / white
- DSR 93-00000-P131 Cat.. 5E / black *
- DSR 98-00000-P130 Cat. 6 / white *
- DSR 98-00000-P131 Cat. / black *



USB-A outlet

- DSR 94-00000-U130 white
- DSR 94-00000-U131 black *



USB-A charging outlet

- DSR 95-00000-U130 white
- DSR 95-00000-U131 black *



USB-C charging outlet

- DSR 97-00000-U130 white
- DSR 97-00000-U131 black *



TV outlet

- DSR 99-00000-U130 white
- DSR 99-00000-U131 black *



SAT outlet

- DSR 2T-00000-1130 white
- DSR 2T-00000-1131 black *



EBERLE analogue ROOM thermostat under plaster mounting

- DSR 3T-00000-1130 white
- DSR 3T-00000-1131 black *



EBERLE analogue FLOOR thermostat under plaster mounting, with sensor

- DSR 4T-00000-1130 white
- DSR 4T-00000-1131 black *



digital thermostat EBERLE universal

- DSR BX-00000-1130 white
- DSR BX-00000-1131 black *



move sensor B.E.G

- DSR BX-00000-1130 white
- DSR BX-00000-1131 black *

i Glass collection offers white and black frame colours together with BTA white/black and OBZ patina handles.



i DSR Z1 / DSR S2 outlets include safety shutters. Connectors for keystone outlets can also be supplied in black color.
* Until stocks are sold out